



## INSTALLATION MANUAL

**Vehicle:** 2004-2008 Ford F150, 2WD and 4WD Chase Kit  
2009-2014 Ford F150, 2WD and 4WD Chase Kit  
2015+ Ford F150, 2WD and 4WD Chase Kit

**Part #** F10UXX

**Level 1 Install:** Bolt on  
**Install Time:** 2 hours (approximate)


**\*\*NOTE:** Read through entire installation manual before deciding whether to attempt the procedure. Do not attempt if you do not possess the proper know-how and tools necessary to complete the installation.

# Chase Kit

**Vehicle:** 2004+ Ford F150, 2WD and 4WD


## Parts List:

- LH & RH Upper Control Arm (UCA)
  - Uniball (installed)
  - Delrin Bushings (installed)
  - Crush sleeves (installed)
  - Baja Kits badges (installed)
  - Zerk fittings (installed)
  - Misalignment spacers (installed)



## Tool List:

- SAE Socket/wrench set
- Metric Socket/wrench set
- Torque wrench
- 1/2" - 12 point socket
- Grease gun



# Chase Kit

1. Lift truck and place on jack stands (chock rear wheels)
2. Remove front wheels
3. Remove stock UCA on both sides
4. Install Baja Kits upper control arm using supplied hardware
  - Reuse the stock upper control arm bolt
  - Torque UCA pivot bolt to manufacturer specifications
  - Torque the 12 point bolt on the spindle to 100 ft-lbs
5. Grease the inner pivots on the UCA



## Chase Kit

6. Put wheels and tires back on and torque to manufacturer specifications
7. Have alignment checked after installation
8. Check and re-torque bolts after the first 500 miles
9. Grease inner pivots as needed or at regular service intervals
10. Follow procedures laid out in the “General Maintenance Manual” for the lifetime of the truck



FOR ANY TECHNICAL QUESTIONS OR  
SUPPORT, PLEASE CONTACT BAJA KITS AT  
949-566-8615

Rev	Description	Date	Initial
-	Initial Release	5/24/2017	JOS